

HydroClenz for BROEN-LAB 1200L Emergency Tank Showers



BROEN-LAB item number: HTS61020
Multiple filter size options view table below

HydroClenz provides constant protection against infestations of pathogenic bacteria in water treatment systems.

Immersed in water, the complex integral electrolytic activity of the ceramic media produces constant oxidising, while the noble metal in the form of a fine matrix format produces ionisation. The ionisation of the noble metal is enhanced by the activity of the ceramic media and the combined effect is to act as a powerful disinfectant producing exceptional kill rates against pathogenic bacteria.

- Scale inhibition and corrosion prevention due to electrolytic activity of the ceramic media
- No handling issues - media is totally inert whilst out of water
- Approved by the WRC (The Water Research Commission) and NAMAS accredited laboratories
- Complies to BS6920 Part 1 and COSSH regulations

Specifications

SERVICES			
USE PERIOD	3 Years		
TANK SIZE	PART NUMBER	LENGTH	DIAMETER
350L	HTS61000	190mm	63.5mm
1200L	HTS61020	445mm	63.5mm
1500L	HTS61040	620mm	63.5mm
2000L	HTS61050	770mm	63.5mm

For more information, please contact your BROEN-LAB representative or use the following information: email: lab@broen-lab.com or tel: + 45 6376 6376

BROEN-LAB